INSTRUCTIONS FOR USE



LUMBAR SUPPORT CUSHION

Lift up the headrest without removing it and attach ad'just® using the Velcro strip.

Position the air pump within arm's reach so that it does not interfere with driving or with safety installations such as the seatbelt or airbag. Shorten the rubber tube if necessary.



Feed the bottom of ad'just® through the gap between the base and the back of the seat

To avoid possible discomfort, position the side cushions so that they do not exert continual pressure on your body. The support they offer will become apparent when taking corners.

A few tips:

Perfect adjustment is rarely achieved straight away. You may need to try a few times before finding the right position.

A good piece of advice: Adapt ad'just® to your needs! Some users often inflate and deflate the cushion, others place it at the bottom of the seat or even vertically...

Warning! This product is only designed for adults and children over the age of 10. Under no circumstances can it be a substitute for an approved child seat.







1 YEAR WARRANTY warranty@adjust.fr

You will need to be seated to adjust the height of the inflatable lumbar support cushion. Slip your hand between the back of the seat and ad'just® and peel off the cushion. Slide it down to the lumbar region of your back and remove your hand when it seems to be most comfortable for you.

The cushion will remain fixed in this position.



® Patent and registered trademark

INSTRUCTIONS FOR USE

adjust

CUSHION SEAT

- 3 REFERENCES:
- SEAT CUSHION WITH SIDE CUSHIONS
- SEAT CUSHION ALONE
- SIDE CUSHIONS ALONE



1 YEAR WARRANTY warranty@adjust.fr

The shape of the seat base **alleviates** nerve and muscular tension

at the base of the back.



The two left and right cushions attach to the main cushion.

Optimize your comfort:

Try out different side-cushion positions to provide optimal side-support when cornering.



The non-slip strips with silicone prevent slippage. -

The cushions are removable and washable (30°C). Take care with the hook fastening areas which can cause damage to other materials.

To relieve any unwanted pressure on the coccyx: Unzip the back of the seat and remove the detachable area.



ATTACH THE BASE CUSHION TO THE LUMBAR SUPPORT CUSHION



ALL PRODUCTS odjut



® Patent and registered trademark

Attach the lumbar support cushion to the headrest.

Then slip the flap between the seat and the back of the chair